

13178

# AIRPORT DIAGRAM

## BALTIMORE/WASHINGTON INTL THURGOOD MARSHALL (BWI)

AL-804 (FAA)

BALTIMORE, MARYLAND

ATIS  
115.1 127.8  
BALTIMORE TOWER  
119.4 257.8  
GND CON  
121.9  
CLNC DEL  
118.05

**D**

324  $\Delta$

RWY 04-22  
PCN 62 F/A/W/T  
S-80, D-220, 2D-600, 2D/2D2-790

RWY 10-28  
PCN 105 F/A/W/T  
S-80, D-220, 2D-1020, 2D/2D2-1340

RWY 15L-33R  
PCN 15 F/A/W/T  
S-30, D-45


RWY 15R-33L  
PCN 70 F/A/W/T  
S-80, D-220, 2D-675, 2D/2D2-890

JANUARY 2010  
ANNUAL RATE OF CHANGE  
0.0° W



NE-3, 29 MAY 2014 to 26 JUN 2014

NE-3, 29 MAY 2014 to 26 JUN 2014



ASDE-X Surveillance System in use.  
Pilots should operate transponders  
with Mode C on all twys and rwy's.

**CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.  
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.**

76°41' W                      76°40' W

# AIRPORT DIAGRAM

BALTIMORE, MARYLAND

## BALTIMORE/WASHINGTON INTL THURGOOD MARSHALL (BWI)

13178